

Defender Mudflap Kit to D2 Installation instructions

1. Front

a. Remove factory front mudflaps and brackets

1. Remove two phillips screws from outer edge of mudflap where it meets rocker trim

1.



2. Remove three factory nuts holding factory bracket to underside of truck

1.



- b. Prepare Defender mudflaps for installation to Extinct brackets
 - 1. If ordering the defender front brackets the mudflaps are riveted to the brackets.
 - 2. Removing the mudflaps from the brackets can be done by drilling out the rivets or grinding off the heads from the bracket side.
- c. Install defender mudflaps to new brackets
 - 1. We recommend putting the brackets toward the tire, the mudflaps toward the rear.
 - 2. Tall section of mudflap goes towards the center of truck - tapered to the outside.
 - 3. Long bolts go through the bracket with the heads toward the tire, then the mudflap with the nuts on the rear. Leave nuts loose for final fitment

1.



- d. Install bracket with attached mudflap on the truck
 - 1. Fit bracket to studs on underside of truck.
 - 2. Install nuts one at a time, pushing up on bracket to enable enough thread engagement. Hand tighten only to allow clearance to adjust extension in or out as desired.

1.



2. Rear

- a. Note: If your factory brackets are rusted replacements are available from Rimmer Bros.com - pn [CAX100200](#) for RH or [CAX100210](#) for LH
- b. Remove factory rear mudflaps from brackets
 - 1. Remove two phillips screws from outer edge of mudflap where it meets rocker trim

1.



- 2. The factory mudflaps are secured to the truck using rivets to the bracket. The easiest method of removal is a cutoff wheel on an angle grinder on the rivet heads. Grinder, sander, file, or hacksaw will also work acceptably.
- c. Install defender mudflaps to new brackets
 - 1. We recommend putting the brackets toward the tire, the mudflaps toward the rear.
 - 2. Tall section of mudflap goes towards the center of truck - tapered to the outside.
 - 3. Long bolts go through the bracket with the heads toward the tire, then the mudflap with the nuts on the rear. Leave nuts loose for final fitment

1.



- d. Install bracket with attached mudflap on the truck
- e. Fit bracket to factory bracket using short screws - screw heads to the back, nuts in the center of the bracket.